

Interactive voice recorder board

with 30 pockets


Instructions (Keep them in a safe place)

The interactive voice recorder board has 30 pockets, each with a small voice recorder. Each voice recorder can record and play back a sequence of up to 30 seconds. Each pocket is made of hard-wearing material and has a cover to protect the contents from moisture.

The interactive voice recorder board has 2 suspension devices with which it can be attached to the wall, for example.

Recording

- Slide the “On/Off/Lock” switch to “On” to be able to make recordings.
- Select the pocket for which you would like to make a recording.
- Press the “Play” button below the pocket to start recording. A short signal tone sounds and the red LED lights up.
- Speak clearly into the microphone. You can record sequences of up to 30 seconds.
- Press the “Play” button again to stop recording. You will hear two short beeps and the red LED goes out.
- Each new recording for a pocket deletes the previous one.



Playback

- Slide the “On/Off/Lock” switch to “Lock” to be able to play back the recordings.
- Press the “Play” button to play the respective recording.
- Slide the “On/Off/Lock” switch to “Off” if you want to switch off the voice recorder panel.

Change batteries

- This product requires 3 x 1.5 V AAA batteries (not included).
- Remove the battery compartment cover and replace the old batteries with the new ones. Ensure that the poles are in the correct position.
- Then reattach the cover.

Further important information

- To clean, wipe the product with a clean, damp cloth.
- Check that the product has been switched off before cleaning.

Battery disposal

This product has been manufactured using high-quality materials and components, which can be recycled and used again. For this reason, we are legally obliged to point out the following:

Batteries must not be disposed of in household waste. As the end user, you are legally obliged to take used batteries to an appropriate collection point. You can take old batteries to your local authority collection points or hand them in at any location where batteries of the relevant type are being sold. You can also hand in batteries free of charge at our dispatch warehouse (see below) or send them back there. If you wish to take advantage of this option, please send your old batteries marked as "used" to the following address:

TimeTEX HERMEDIA Verlag GmbH
Ländenstraße 10 · 93339 Riedenburg · Germany

TimeTEX HERMEDIA Verlag GmbH
Deggendorferstr. 5 · 4030 Linz · Austria

TimeTEX HERMEDIA Verlag GmbH
Stemmerstr. 54 · 8238 Büsingen · Switzerland

Please note, our obligation to take back old batteries is limited to the types of batteries currently or previously available as new in our product range, and in the customary quantities expected for end users.

Old batteries contain valuable raw materials that can be recycled.

The crossed-out wheellie bin means: disposable and rechargeable batteries must not be disposed of in household waste.

Pb: Battery contains over 0.004 percent by mass lead

Cd: Battery contains over 0.002 percent by mass cadmium

Hg: Battery contains over 0.0005 percent by mass mercury



Electronic device disposal

The "crossed-out wheellie bin" sign means: electrical and electronic devices must not be disposed of via household waste. These devices should, in fact, be collected separately from unsorted residential waste and can be handed in free of charge at a local authority collection point. Old disposable or rechargeable batteries that are not sealed inside the old device should be removed before it is handed in at the fixed collection point. You must take your own responsibility for deleting any personal data on old devices for disposal.



WEEE-Reg.-Nr.: 79696058 | ARA/ERA number: 40640

Manufacturer:

TTS Group LTD
Unit 1, Park Lane Business Park
Kirkby-in-Ashfield
Nottinghamshire
NG17 9GU
UK

Distribution:

TimeTEX
HERMEDIA Verlag GmbH
Ländenstraße 10
93339 Riedenburg
Germany



Caution!
Not suitable for children
under
36 months.
Choking hazard.
Small parts.

©TimeTEX HERMEDIA Verlag GmbH
Ländenstraße 10 · 93339 Riedenburg · Germany
TimeTEX AT · Linz | TimeTEX CH · Büsingen

Store packaging as proof.

www.timetex.com
info@timetex.com

Art. 62628